Control Box Selection								
Control Box #	0350	0351	0352	0353	ECO-0350	ECO-0351	ECO-0352	ECO-035
# of Exh / Sup Fans - Single Phase or VFD	1/1	2/2	3/3	4/4	1/1	2/2	3/3	4/4
# of Exh / Sup Fans - Three Phase no VFD	Χ	1/1	1/1	2/2	Χ	Х	Х	Χ
A/C Fans								
10D	/	/	/	/	X	Х	Х	Х
20D	√	✓	√	√	X	X	X	X
28D	√	√	√	√	X	X	X	X
28B	√	√	√	√	X	X	X	X
36B	√	√	√	√	X	X	X	X
48B	✓	√	√	✓	X	X	X	X
52B	X	√	√	✓	X	X	X	X
72B	X	√	√	√	X	X	X	X
85B	X	√	√	√	X	X	X	X
SF5	✓	√	√	√	X	X	X	X
SF7	√	√	√	√	X	X	X	X
SF8	√	√	√	√	X	X	X	X
SF9	X	√	√	√	X	X	X	X
SF10	X	√	√	√	X	X	X	X
SF11	X	√	√	√	X	X	X	X
EC Fans		•	•	•		/\	/\	
10D-ECA	√	✓	√	/	/	√	√	✓
20D-ECA	√	√	√	√	V	√	√	√
28D-ECA	√	√						
36D-ECA	√	√						
48D-ECA	√	√						
SF5D-ECA	√	√						
SF7D-ECA	√	√						
SF8D-ECA	✓	√	√	✓	√	√	√	√
SF9D-ECA	✓	√	√	✓	V	√	√	√
Fan HP		V	V	V	V	V	V	V
115/1/60 - 1HP	/	/	√	/	X	Х	Х	Х
230/1/60 - 1 HP	√	√	√	√	X	X	X	X
230/3/60 - 2 HP - No VFD	X	√	√	√	X	X	X	X
460/3/60 - 5 HP - No VFD	X	√	√	√	X	X	X	X
230/3/60 or 460/3/60 - Any HP with VFD	✓	√	√	✓	✓		✓ /	✓

All control boxes <u>include</u> the following: Hood Sensor, Seal, Room Sensor, Shunt Trip Signaling